

TOPLoc Fascia Fastener Installation Instructions

TimberTech Fascia Boards

Using screws with proper installation of TimberTech Fascia provides the best long-term holding. TimberTech recommends the use of TimberTech TOPLoc Fascia Fasteners for best results.

**One box covers approximately 100 ln. ft. of fascia.
Installation also requires one TOPLoc Fascia Bit.**

For use with TOPLoc Fascia Fasteners:

- Using the TOPLoc Fascia Bit, pre-drill 2" from the top and bottom alternating a maximum of 12". It is recommended that screws are evenly spaced for best look.
- Set fascia in place. Be sure to follow proper gapping requirements.

- Drive TOPLoc fascia fastener 90 degrees with the fascia surface so that the screw head is flush with the surface. Do not completely torque down screw; screw should serve as a hanging mechanism to allow for expansion and contraction in the fascia. This will help to prevent any undesired consequences to movement in the fascia.
- Continue fastening in pattern described being sure to work left to right or right to left. This will ensure flatness of the fascia.

