



**Keeps Paint Out. Keeps Lines Sharp.®**

## HOW TO APPLY

There are no special techniques or methods that you need to use with FrogTape. Here are some general tips for applying painter's tape to trim or other surfaces.



### Applying Painter's Tape:

- 1 Clean the surface to be masked. Make sure it is dust-free and dry.
- 2 If the surface has been recently painted, make sure the paint has cured. Please refer to the FAQ page of FrogTape.com for more information about cured paint.
- 3 For accurate placement, adhere FrogTape in short sections to avoid stretching the tape.
- 4 Make sure FrogTape is flush to the edge that you will be painting.
- 5 Using a putty knife or 5-in-1 tool, press the tape you laid to burnish it to the surface you are masking.
  - If you are taping on a textured surface, some specialized taping techniques might be required. See the "How to Tape on Textures" article for more information.



Scan to view the video tutorial

**YouTube™** [youtube.com/frogtapetube](https://youtube.com/frogtapetube)

**Still have questions? Please call 1-877-FROGTAPE, 8 am to 5 pm EST to speak with a live representative.**

NOTE: FrogTape was designed for use with latex paints for interior/exterior home painting projects. If you wish to use FrogTape in another application you must test before use. Please see the tape core or the FAQ section of FrogTape.com for more information.