


Weight capacity : 75 kgs/ 165 Lbs






NOTE: 50% TIGHTEN BEFORE FIXING ALL BOLTS & SCREWS


COMPONENTS LIST

I







Q'TY 1

II




Q'TY 4


HARDWARE LIST

A		8	Hex. Nut	C		8	Washer
B		8	Washer	D		1	Spanner


Step 1




Step 2




Step 3




Step 4





Maximum Weight Capacity 110Kgs/ 242Lbs





NOTE: 50% TIGHTEN BEFORE FIXING ALL BOLTS & SCREWS


COMPONENTS LIST

<p>I</p> <p>Q'TY: 2 (Right & Left)</p>	<p>II</p> <p>Q'TY: 1</p>	<p>III</p> <p>Q'TY: 1</p>
<p>IV</p> <p>Q'TY: 1</p>		

HARDWARE LIST

A		8	Screw 7x 70	B		2	Allen Key
---	--	---	-------------	---	--	---	-----------


Step 1



Lắp kết nối lưng tựa (III), mê ngồi (II) với cụm hông chân (I) bởi các vít (A) và siết chặt khoảng 50 % tất cả các vít (A).

Dùng khóa lục giác (B) siết chặt lại tất cả các vít (A)

Step 2



Đặt nệm (IV) vào mê ngồi và cột dây có sẵn trên nệm vào 2 chân sau của ghế

Step 3

